


General Information

XView is X-ray image evaluation software that works with an X-ray CMOS camera, X-Point Super Zero. You can optimize the camera settings in real time when importing the image to the PC while controlling various camera parameters with the menu located on the left side of the image.



Contents

- ⇐ Start and Stop the capture, Freeze image
- ⇐ Save image Copy temporarily save image on Clip board
- ⇐ Realtime image accumulation for lowering random noise
- ⇐ Binning Summing 2×2 , 4×4 pixel data contributes to reduce image file volume and increase sensitivity. On the other hands Image display size reduces to 1/2 ,1/4 against original image size.
- ⇐ Compressing and Enhancing the contrast by adjusting Max, Min range
- ⇐ Frame rate control for sensing up in conjunction with exposure time
- ⇐ Exposure time control for sensing up in conjunction with frame rate
- ⇐ Gain control , Boost contributes Max gain extension.
- ⇐ Edge Enhance control
- ⇐ Hot Pixel Correction
By long exposure, high gain, etc. to increase the camera sensitivity. Many white spots called hot pixel may appear on the image. You can eliminate this hot pixels by adjusting these parameter.